




new application FEATURES






The **Home** screen is where your EPIC experience begins. Watch a video tutorial that walks you through the app's newest features. You'll also see your recently viewed channels and quick links to categories like News, Sports, and Movies—making it easy to jump right back into what you love.




To open the **TV Guide**, simply arrow right from the main menu. Scroll through channels to see what's on now, next, and later. The new design offers smooth scrolling and clear program details, helping you plan your viewing with ease.




Create your own personalized guide filled with only the channels you watch most. While viewing a program, press the **Down** arrow to open the timeline and select the heart icon to add that channel to your **Favorites** list. It's a quick way to keep your top picks front and center.



In the **Recordings** section, you'll find every show you've recorded or scheduled to record. Recordings are organized into single episodes, series, and those set to expire soon. From here, you can play, manage, or delete recordings anytime.





The new **Search** function helps you find exactly what you're looking for. Type a program name, actor, or keyword to see results across live, future, and on-demand content. You can even set a recording right from the search results.



In **Settings**, you'll find all the tools to customize your viewing experience. Adjust general and network preferences, set parental controls, review device info, and log out when needed. This is where you tailor EPIC IPTV to fit your household.

main menu





The **Navigation Circle** lets you move through the guide easily.

- **Up / Down:** browse through channels
- **Left / Right:** move through different times of the day

The center button inside the navigation circle is the **Select** button.


- Press **Select** on a program to open options to Watch Live TV, Record, or Create a Series Recording.

While watching a program, press the **Back** button to return to the guide.

- Continue to press the **Back** button to return to the Main Menu. You may need to press it several times.


Each remote may look slightly different, but all include:

- A **Navigation Circle or Pad** for movement
- A center **Select** button for choices
- A **Back** button for returning to previous screens




guide navigation






Start by opening the **Settings** menu from the Main Menu. This is where you can personalize how your TV guide looks and feels.



Next, navigate over to **TV Guide**.




Then choose **Channel Rows**.

The number of rows you select determines the size of the text in your guide. Fewer rows create a larger, easier-to-read font. More rows display additional channels on the screen, but with smaller text.

guide rows & font size




For users watching EPIC IPTV on popular streaming devices like Amazon Firestick there are two ways to move through channels.
(Note: These instructions do not apply to viewers using a BSD (BEK Streaming Device).



1. Navigate Through the Guide

Use the navigation circle on your remote to move through the guide. Up/Down to scroll through channels. Left/Right to move through different times of the day.

Highlight a channel you'd like to watch, then press the **Select** button in the center of the navigation circle to tune in.




2. Use the On-Screen Timeline

While watching a program, press **DOWN** on the navigation circle on your remote to open the timeline and options menu at the bottom of the screen. From here, navigate down to the **Next Channel** or **Previous Channel** icons. Press the **Select** button to move up or down through channels right from the timeline view.

channel surfing



While watching a program, press **DOWN** on the navigation circle on your remote to open the timeline and options menu at the bottom of the screen.



EPG

Select the EPG icon to return directly to the TV Guide. It's a fast way to browse what's on without backing out of live TV.

Keypad

The Keypad icon allows you to type in a channel number manually, so you can jump straight to the channel you want.

Previous Channel

Use the Previous Channel option to flip back and forth between the last two channels you've watched.

CC


The Closed Caption (CC) icon lets you turn subtitles on or off anytime while watching.

Info

Info icon to bring up program details, including the show name, a brief description, and options to record or set a series recording.

timeline options menu





Creating your Favorites Guide is a great way to personalize your viewing experience and keep your most-watched channels easy to find.

Adding a Favorite Channel

While watching a program, press the **Down** button on your remote to open the timeline and options menu. From there, select the heart icon to add that channel to your **Favorites** Guide. Once selected, the heart will fill in to confirm it's been added.

Switching to the Favorites Guide

To view your **Favorites**, return to the TV Guide. Press the **Back** button until the **All Channels** filter is highlighted at the top of your guide. Then, arrow over to **Favorites** to display only the channels you've saved. This allows you to scroll through just your personal lineup.

Accessing Favorites from the Main Menu

You can also access your Favorites directly from the Main Menu by selecting **Favorites**. This section shows a complete list of your saved channels.



Editing Your Favorites List

To remove a channel, navigate to the **Edit** button. An X will appear on each favorite channel. Select the channel(s) you want to remove, and then choose **Confirm** to finalize the change.

With these steps, your Favorites Guide stays organized and customized exactly how you like it.


favorites guide





To start, find the program you'd like to record in the Guide. Once it's highlighted, press the **Select** button on your remote. A menu will appear with options to Watch Live TV, Record, or Create a Series Recording. Choose the option that fits your needs.

After you've set a recording, you'll see a clear recording indicator appear on that program in the guide—so you'll always know what's scheduled.




To watch your recordings, go to the **Main Menu** and select **Recordings**. Your shows are organized into Single, Series, and Expiring Soon categories. From here, you can play, manage, or delete recordings anytime.

To delete, select the **Edit** button in the upper-right corner. All recording tiles will show an X. Highlight the recording(s) you want to remove and press **Select**. When you're done, choose **Confirm** in the upper-right corner to finalize the deletion.

EPIC DVR puts you in charge—record what you love and watch whenever you want.

setting the dvr





With **TimeWarp TV**, you can go back and watch select programs that aired up to 72 hours ago—right from your guide.


To use this feature, open the **TV Guide** and navigate backward through the schedule until you find the program you want to watch. Once it's highlighted, press the **Select** button on your remote.

You'll then see options to Watch, Record, or Create a Series Recording for that past program. Choose your preference and enjoy catching up on what you missed—no need to have recorded it in advance.

TimeWarp TV gives you the flexibility to rewind your week and watch on your own schedule.

timewarp tv





The fastest way to type in the EPIC IPTV app is by scanning the QR code that appears on your screen. This allows you to use your mobile device's browser to enter text quickly and easily.

If that isn't an option, you can use your remote's **Navigation Circle** to move across the on-screen keyboard. Use the **Select** button in the center to input each character.

Refer to the labels on the keyboard diagram to understand what the special buttons do. One important detail to remember:

- The **Delete** button removes one character at a time.
- The **Clear** button erases all text in the typing field at once.

When you're finished typing, be sure to select the **Next** button to input what you've typed and move to the next field or confirm your entry.

With a little practice, you'll be able to navigate and type efficiently using either your mobile device or your remote.

keyboard tips





Want to see the EPIC IPTV features in action? We've made it easy to learn right from your screen.


Inside the EPIC App

On your TV, navigate to the **Home** screen from the **Main Menu**. At the top, you'll find a video tutorial that gives a quick overview of all the new features available in the EPIC IPTV app. It's the fastest way to get familiar with your new viewing experience.

On the BEK Website

BEK also provides a collection of feature-specific tutorial videos on our website. Each short video walks you through individual tools—like using the guide, managing recordings, setting up favorites, and more.


Scan the QR codes to watch or visit www.bek.coop/epic and scroll down to "What's New in the Latest Update" to find links to all of the tutorial videos.




Overview




Recordings
Menu



Favorites
Menu



Search Function
& Settings Menu



Navigation
Tips

tutorial videos





bek.coop/epic | 701.475.2361

